TOP AND CONSOLE PARTS

For Model: RGX4625EW3
(White)

GAS DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: RGX4625EW3
(White)

Illus. No.	Part No.	DESCRIPTION
1	3397545	Panel, Rear Console
2	693995	Screw, Hex Washer Head
3	3397269	Connector, Timer
4	3358013	Cap, End (L.H.)
5	3936144	Connector
6	3395683	Connector (Motor)
7	3357995	Cap, End (R.H.)
8	357213	Nut, Push−In (2)
10	339392	Screen, Lint
11	688150	Cover, Lint Screen
12	339229	Hinge, R.H.
	339230	Hinge, L.H.
13	688983	Screw, 8−18 x 5/8
14	388326	Screw, Console
15	3394427	Clip, Harness
16	3396022	Top
17	688805	Clip
18	94614	Terminal
19	3400859	Screw, Grounding
21	3976568	Timer Assembly, 60 Hz.
23	3394293	Harness, Wiring
24	3403499	Connector, 2−Position (Gas Valve)
25	3403498	Connector, 3−Position (Gas Valve)
29	3390646	Screw, 8−18 x 5/16
39	3395382	Switch, Push−To−Start
48	3977122	Timer Knob & Dial
53	8054298	Bracket, Control
54	3405702	Panel, Control
75	717252	Receptacle
81	3352875	Knob, Push−To−Start

LITERATURE AND OPTIONAL PARTS

Illus. No.	Part No.	DESCRIPTION
LITERATURE PARTS		
	LIT3406075	Guide, Use & Care
	LIT3405338	Instructions, Installation
	LIT3406688	Label, Wiring Diagram
OPTIONAL PARTS NOT INCLUDED		
PAINT, TOUCH−UP (1/2oz.)		
	72017	White
	72107	Almond
PAINT, PRESSURIZED SPRAY (13 oz.)		
	350930	White
	350956	Almond
	350938	Primer, Gray
PAINT, BULK (1 qt.)		
	799344	White (Uncut)
	978883	Almond (Uncut)

CABINET PARTS

For Model: RGX4625EW3
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: RGX4625EW3
(White)

Illus. No.	Part No.	DESCRIPTION
1	697776	Screw, 10−32 x 5/8
2	343641	Screw, 10−16 x 1/2
3	693995	Screw, Hex Head
4	3403630	Plug, Strike Hole
5	3396795	Cover, Block
6	3394975	Plug, Front Panel
7	3396807	Panel, Rear
10	3406104	Door Switch Assembly
11	697773	Screw, 6−20 x 7/8
12	238614	Bumper
13	3404413	Plug, Hinge Hole (4)
14	342055	Screw, 8−18 x 1/2
15	3394083	Clip, Front Panel
16	3392100	Foot, Dryer (4)
18	3399580	Cabinet Assembly (Includes Illus. Nos. 5, 7, 15, 16 & 57)
19	98234	Clip, Ground (2)
20	690363	Lock, Front Top (2)
21	3403574	Front Panel Assembly
23	685203	Clip, Felt Pad
24	690081	Catch, Door
28	3405514	Hinge & Pin Assembly (2)
33	3403431	Strike, Door
35	3403371	Door, Rear
36	3403361	Door, Front
37	3405184	Handle, Door
38	349464	Seal & Bearing Assembly
42	3405245	Seal, Door
45	344020	Cord, Power
51	238088	Hinge, Top (2)
53	691366	Idler & Pulley Assembly
56	660996	Belt, Drive
57	348780	Base, Motor
58	3400500	Bolt, 5/16−18 x 3/4
59	3394341	Pulley, 60 Hz.
62	3976707	Motor, 60 Hz.
63	660658	Clamp, Motor
64	3404162	Clamp, Motor (W/Shield)
67	3402844	Burner Assembly, 60 Hz. (Refer To Pages 5 & 6 For Further Breakdown)
68	341029	Clamp, Pipe
69	694572	Kit, Conversion (Type 1, 2 & 3 To Type 4)
85	3401775	Valve, Gas 60 Hz. (Complete)
86	686590	Ignitor
87	3393909	Screw & Washer
88	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
89	694540	Coil, 60 Hz. (2 Terminal) (Main)
90	694421	Screw, Bracket Mounting (8−32 x 1/2)
91	694538	Bracket, Coil
93	694424	Leak Limiter
94	694423	Screw, Regulator Adjustment
95	694422	Spring, Regulator
97	239822	Plug, Pipe

3402844 BURNER ASSEMBLY

For Model: RGX4625EW3
(White)

USE WITH TYPE 1 − NATURAL, TYPE 2 − MIXED, TYPE 3 − MANUFACTURED AND TYPE 4 − LIQUEFIED PROPANE AND BUTANE GASES



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

3402844 BURNER ASSEMBLY

For Model: RGX4625EW3
(White)

USE WITH TYPE 1 − NATURAL, TYPE 2 − MIXED, TYPE 3 − MANUFACTURED AND TYPE 4 − LIQUEFIED PROPANE AND BUTANE GASES

Illus. No.	Part No.	DESCRIPTION
1	3402844	Burner Assembly 60 Hz. (Type 1, 2 & 3) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8−32 x 5/8)
6	343641	Screw, 10−16 x 1/2
7	693986	Base, Burner
8	3387057	Screw, 8−18 x 3/8 (2)
9		Orifice, Burner
	234826	Type 1
	15775	Type 2
	15419	Type 3
	229742	Type 4 (Butane)
	234868	Type 4 (Propane)
10	3401775	Valve, 60 Hz.
11	694421	Screw, 8−32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
20	239822	Plug, Pipe
21	233273	Pipe, Gas Supply
22	3406052	Elbow Union Assembly
23	3393767	Pipe, Tail
24	233076	Nut, Compression
25	341029	Clamp, Pipe

Following Parts Not Illustrated

694572	Conversion Kit (Type 1, 2 & 3) to Type (4) L.P.G.

BA−141

BULKHEAD PARTS

For Model: RGX4625EW3
(White)



Illus. No.	Part No.	DESCRIPTION
1	694283	Lint Chute Assembly
2	343641	Screw, 10−16 x 1/2
3	3406022	Bracket, Bulkhead
4	3388703	Washer, Support
5	90767	Screw, 8−18 x 3/8
6	3392519	Fuse, Thermal
7	347139	Seal, Lint Chute
8	660039	Thermostat, 150°F (66°C)
9	3977358	Drum Hole Plug
10	694089	Wheel, Blower
11	3405016	Housing, Blower
12	3398161	Clip
13	489463	Screw, 8−18 x 5/8
14	3394343	Box, Heater
15	3403140	Thermostat, 205°F (96C)
18	8066048	Funnel, Burner
24	696302	Shield, Exhaust
26	3392247	Pad, Blower Housing
27	3394196	Seal, Blower Shaft
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397588	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8−16
48	3397264	Bulkhead
49	338906	Sensor, Radiant
62	3394509	Ring, Bearing
63	97787	Screw, 11−16 x 3/4
66	337449	Seal, Rear Drum
67	3396777	Drum Assembly
68	342847	Baffle, Drum
69	3976435	Bracket, Support
70	90296	Clip
73	339956	Seal

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST